

選択したモード	該当する Control mode	該当する Support mode
PRVC	PRVC	Volume Support
Volume Control	Volume control	Volume Support
Pressure Control	Pressure control	Pressure Support